

Installation and User Guide for LCD135C Bluetooth App (Android Version)

1- Installation

A. Locate the Installation Package

- Open the "File Manager" on your phone
- Navigate to the folder where the file was saved, typically:

Internal Storage > Download > WeiXin (if received via WeChat).



B. Correct the File Extension

- The installation package file has the suffix ".apk".
- When receiving the package via WeChat or other sources, additional characters (such as ".1") may be appended after ".apk".
- In this case, please **rename** the file to remove these extra characters and restore the correct ".apk" extension before proceeding.

C. Screen Saver Security

- Install the screen saver and configure it to require a secure password for access upon resume.
- This ensures that unauthorized users cannot access the device when it is idle.

2- Main Interface



The user-friendly main interface allows you to effortlessly manage gear shifting (Increase/Decrease), toggle headlights, monitor Bluetooth status, use navigation, and access comprehensive system settings.

Speed – Real-time readout in mph or km/h (switchable in settings).

Battery – Visual bar plus percentage for at-a-glance monitoring.



Odometer/Trip – Shows current trip distance in miles or kilometers.

3- Connect to the Bluetooth display

Typically, after launching the app, it will automatically reconnect to the display you used last time, no extra steps needed.

If it doesn't connect automatically, you can pair it manually:

- Tap the Settings icon (gear symbol) in the top right corner.
- Select Reconnect Bike from the bottom menu.
- Pick your display from the device list (the default name is **MyeBike**).



4- Overview of Settings

Change Name: Give your device a custom name (up to 17 characters). Setting a unique name right away makes it easier to spot your bike later.

Change Password: Set a new 6-digit Bluetooth password. The default is 123456, it's a good idea to change it during setup for better security.

Reconnect Bike: Manually search for and connect to your bike's Bluetooth display.

Lock Bike: When you lock the bike through the app, the display turns off. If someone presses the power button while it's locked, the display will show a **Bluetooth Lock icon**. The display powers back on automatically once the app reconnects.

Charts: View real-time riding data, including speed, current, and voltage, shown as dynamic curves.

Exit: Securely close and exit the application.

Reset Password: This resets the app password to 123456. To complete the reset, you'll also need to initialize the Bluetooth settings from the display's physical settings menu. After that, the device name returns to "MyeBike" and the password to 123456.

Advanced Parameter Settings: Upon entering this menu, the app automatically **synchronizes** with the parameters stored on the display. After making changes, tap "Save" to upload them—the display will then update the controller accordingly.

